## IS-5041 Self-Install (Replacement STB installation)

To ensure the successful installation of your IS-5041 STB, read and follow the step-by-step instructions below.



## 1. Do you have all of the necessary equipment?

- a. IS-5041 STB
- **b. Remote Control** (This remote control is already programmed to operate your STB. Instructions on how to program your remote to operate your TV or other devices are available from your service provider.)
- c. HDMI Cord
- **d. Ethernet Cable** (already connected to a wall jack at one end)
- e. Power Cord



- 2. Make sure your TV is turned off.
- 3. Connect the HDMI cable from the HDMI port on the back of the STB to the HDMI input on your TV.




4. Connect the Ethernet Cable into the back of the STB.



5. Plug one end of the STB power cord into the STB, and then the other end into the power outlet.



- 6. Turn on your TV. Make sure that your TV is set to the proper input.
- 7. Power on your STB, if it is not already.
- 8. As your STB loads, you will see a welcome screen indicating the STB is loading.



9. Live TV will appear. Channel surf away and enjoy the feature-rich video service at your fingertips!